


Open the door to dry dishes

Advanced AirDry technology maximises drying performance using natural airflow. The door automatically opens 10cm in the final stage of the cycle, drying dishes naturally and effectively. AirDry performs three times better than closed-door systems.

Product Benefits & Features



Open-door drying with AirDry

AirDry technology delivers up to three times better drying performance when compared to closed-door systems. The door automatically opens at the end of the drying phase and air is circulated inside the machine. Dishes emerge perfectly dry. Every time.

Rinse off your dishes when the dishwasher is not yet full

When your dishwasher is only half full, you may want to wait before you run a full cycle. The Rinse & Hold program quickly rinses partial loads of dirty dishes, minimising unpleasant smells and keeping bacteria at bay.

- SENSORLOGIC dishwasher
- LED display
- Warm water 60°C
- 4 programmes, 3 temperatures
- Dishwasher programmes: 90 Minutes, Eco, Intensive 70°, Rinse & Hold
- Options:None
- Delay start option: 3h
- Inverter motor
- Height adjustable upper basket
- Upper basket with
- Cutlery basket
- Lower basket with Fixed plate racks
- AQUA-CONTROL
- Installation in height
- Anti fingerprint stainless steel finishing
- Panel with symbols
- Indications for salt and rinse aid

