AEG

FSE73507P







Customisable dishwashing. Efficient cleaning

The 7000 MaxiFlex Drawer fits different types of utensils. From multiple cutlery sets to oversized utensils. Flexible dividers mean every load is customisable. It's the ultimate in efficient, convenient cleaning.

Product Benefits & Features



Customisable space and convenient cleaning with MaxiFlex The MaxiFlex drawer is engineered to accommodate

cutlery and utensils of many sizes, whether large or awkwardly shaped. Flexible dividers and maximised depth mean each load is customisable. Essentially every item is seamlessly loaded and cleaned in one go.



SatelliteClean®. Powerful dishwashing. Without using extra water

Even closely stacked or larger dishes receive deep cleaning with SatelliteClean®. The innovative spray arm guarantees corner-to-corner cleaning. With up to 3x better spray coverage providing stunning results across every surface.



Customisable eco dishwashing with just a touch

With the 6000 QuickSelect Dishwasher you can use the My Time slider to select the cycle time, the Ecometer will display the eco performance for each of the possible selections. So, you can easily select the best option with just a touch.

Water reaches every corner. With the Dual Spray Arms

Ensure maximum water coverage with two spray arms. The rotating sprinklers send water jets into every corner of both the lower and upper basket, for dishwashing results you can rely on.

QuickLift—adjust the basket height even when fully loaded Indulge in the efficient amenities provided by the QuickLift basket. Regardless if you have a full load with bulky items, you can effortlessly adjust the height so you can easily fit dishes and kitchen tools of different shapes and sizes.

- 44dB ExtraSilent 42dB
- · Water sensor detects the level of dirt and adjusts water consumption
- LED Display with QuickSelect
- Touch control for programs and functions selection
- AutoOff
- Warm water 60°C
- 7 programmes, 4 temperatures
- Dishwasher programmes: 160 Minutes, 60 Minutes, 90 Minutes, AUTO
- Sense, Eco, Machine Care, Quick 30 Minutes • Options:Extra Silent, GlassCare, XtraPower
- Ceiling shower
- Dual Spray Arm
- Satellite Spray arm
- Delay start option from 1 to 24 hours
- Remaining time
- SpotControl with 2 colours
- Buzzer
 - Inverter motor
 - Sliding door 645-776 mm
 - Height adjustable upper basket, even when fully loaded
 - Upper basket with 2 Red Soft Grips, 2 Red softspikes, Plastic coloured handle
 - MaxiFlex cutlery drawer with knife support
 - · Lower basket with 4 foldable plate racks, Plastic coloured handle
 - AQUA-CONTROL
 - · Installation in height
 - · Indications for salt and rinse aid

AEG

FSE73507P

Product	Specification

Product Number Code	911 077 024
EPRELRegCodeE20	222977
Bar code	7332543736911
EnergyClassE20	D
EnergyCons100CycleE20	67
RatedCapacityE20	10
WaterConsE20	9.9
ProgrammeDurE20	4:00
NoiseClassE20	В
NoisedBAE20	44
OffModePwE20	0.5
StandByPwE20	0.5
Installation in height	Yes
Installation	FI
Inlet hose type of	Aqua control
Anti-flood device	Floating switch
Water supply	Cold or hot
DelayStartE20	4
Dishwasher programs	160 Minutes, 60 Minutes, 90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes
Panel colour	Black
Required fuse (A)	10
Connected load (W)	1950
Voltage	220-240

Cord length external	1.5
Height total	818
Width mm	446
Depth mm	550
Built in depth mm	550
Built in height (min), mm	820
Built in width mm	450
Weight gross cleaner and accessories with packaging	35.73
Weight net cleaner and accessories no packaging	34.25
Package heigth	870
Package width	490
Package depth	685
Weight package Paper/Carton	3
Weight package Wood	162
Weight package PE	190
Weight package PP	0
Weight package Polystyrene (EPS/EPP)	880
Country of origin	PL

PSGBDW210DE00007

