



Customisable dishwashing. Efficient cleaning

The 7000 MaxiFlex Drawer fits different types of utensils. From multiple cutlery sets to oversized utensils. Flexible dividers mean every load is customisable. It's the ultimate in efficient, convenient cleaning.

Product Benefits & Features

Customisable space and convenient cleaning with MaxiFlex

The MaxiFlex drawer is engineered to accommodate cutlery and utensils of many sizes, whether large or awkwardly shaped. Flexible dividers and maximised depth mean each load is customisable. Essentially every item is seamlessly loaded and cleaned in one go.



- 42dB - ExtraSilent 40dB
- Sensorlogic Dishwasher in AutoSense program
- Water sensor detects the level of dirt and adjusts water consumption
- LED Display with QuickSelect
- Touch control for programs and functions selection
- AutoOff
- Warm water 60°C
- 7 programmes, 4 temperatures
- Dishwasher programmes: 160 Minutes, 60 Minutes, 90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes
- Options: Extra Silent, GlassCare, XtraPower
- Ceiling shower
- ProWater system with extra ceiling spraying arm
- ProClean Satellite Spray arm
- Delay start option from 1 to 24 hours
- Remaining time
- SpotControl with 2 colours
- Buzzer
- Inverter motor
- XXL tub
- Sliding door 670-825 mm
- Height adjustable upper basket, even when fully loaded
- Upper basket with 2 Foldable racks, 2 Foldable wires for glasses, 2 Soft Spikes, 6 wine glass soft grips, Plastic handle AEG
- MaxiFlexPlus cutlery drawer
- Lower basket with 2 foldable plate racks, Plastic handle
- AQUA-CONTROL
- Installation in height
- GlassProtectionSystem
- Indications for salt and rinse aid

SatelliteClean®. Powerful dishwashing. Without using extra water

Even closely stacked or larger dishes receive deep cleaning with SatelliteClean®. The innovative spray arm guarantees corner-to-corner cleaning. With up to 3x better spray coverage providing stunning results across every surface.



Customisable eco dishwashing with just a touch

With the 6000 QuickSelect Dishwasher you can use the My Time slider to select the cycle time, the Ecometer will display the eco performance for each of the possible selections. So, you can easily select the best option with just a touch.



At-a-glance check

This dishwasher has a clever way to keep you fully up to date with the status of your dishes. Its beam-on-floor technology projects a red light onto the floor while the cycle is still in progress. And when everything is ready to unload, it switches to a green one. Simple, and effective.

Open the door to dry dishes

AirDry delivers up to 3x better drying performance when compared to closed-door systems. The door automatically opens at the end of the drying phase and air is circulated inside the machine. Dishes emerge perfectly dry. Every time.

Product Specification

Product Number Code	911 434 762	Cord length external	1.6
EPRELRegCodeE20	723136	Height total	818
Bar code	7332543810703	Width mm	596
EnergyClassE20	C	Depth mm	550
EnergyCons100CycleE20	76	Built in depth mm	570
RatedCapacityE20	15	Built in height (min), mm	820
WaterConsE20	11	Built in width mm	600
ProgrammeDurE20	4:00	Weight gross cleaner and accessories with packaging	40.1
NoiseClassE20	B	Weight net cleaner and accessories no packaging	38.39
NoisedBAE20	42	Package height	870
OffModePwE20	0.5	Package width	635
StandByPwE20	0.5	Package depth	680
Installation in height	Yes	Weight package Corrugated Cardboard	120
Installation	FI	Weight package Paper/Carton	10.5
Inlet hose type of	Aqua control	Weight package Wood	300
Anti-flood device	Floating switch	Weight package PE	281
Water supply	Cold or hot	Weight package PP	40
DelayStartE20	4	Weight package Polystyrene (EPS/EPP)	957
Dishwasher programs	160 Minutes, 60 Minutes, 90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes	Weight package Rubber	2
Panel colour	Black	Country of origin	IT
Required fuse (A)	10		
Connected load (W)	1550-2200		
Voltage	200-240		

